

# STICKPRO™

# WHEEL WEIGHT PRE-CLEANING WIPES



## THE TIRE PROFESSIONAL'S CHOICE

Having a clean wheel is the key to success for quick & easy balancing



**HEAVY-DUTY  
PRE-SOAKED TOWELS**



**DESIGNED FOR  
ADHESIVE WEIGHTS**



**FAST AND  
EFFICIENT**



**CLEANS 200+  
WHEELS**



**NO RINSE  
SURFACE PREP**



**EASY TO  
USE**



**VISIT [STICKPROWIPES.COM](http://STICKPROWIPES.COM) TO VIEW THE VIDEO**

Part number : 44012

# ADHESIVE WHEEL WEIGHT INSTALLATION INSTRUCTIONS

## STEP 1 - CLEANING



Clean the area where the wheel weight is to be applied using StickPro wheel weight pre-cleaning wipes.

## STEP 2 - SELECT WEIGHT SIZE



Break or tear the adhesive weights apart depending on the size of weights needed.

## STEP 3 - CONTOURING



If the adhesive weight is not precontoured follow the instructions below, otherwise go directly to step 4. Before removing the liner, apply the weight against the wheel and using your fingers gently contour the shape to the radius of the wheel.

## STEP 4 - REMOVING LINER



Remove the liner and avoid touching the exposed adhesive.

## STEP 5 - APPLYING



Center the weight to the imbalance point. Using your fingers, apply a uniform pressure throughout the surface (do not use a hammer).

#45034

FOR MORE INFORMATION, PLEASE CONTACT OUR CUSTOMER SERVICE TEAM AT 1-800-611-7074.

