



- Activates, reads and relearns all known sensors
- Enhanced, at-a-glance diagnostics status screen
- Fast OBDII relearn for most vehicles
- Program MX-Sensors to replace 99% of OE sensors
- Copy By OBD sensor programming for faster service
- Four MX-Sensor program modes; batch program up to 20 MX-Sensors
- Includes wireless Bluetooth vehicle communication interface (VCI)
- Tire pressure placard value reset
- Read/Clear TPMS system codes & view live data
- Free Wi-Fi software updates for the life of the tool

Visit Product Page

WORKS WITH:

PROGRAMMABLE UNIVERSAL TPMS SENSOR

[Visit Product Page](#) **AUT-1-Sensor**

CLICK FOR VIDEO: INTRODUCTION

99% Vehicle Coverage



FLYER

FUNCTION LIST

CLICK FOR VIDEO: UNBOXING



USER MANUAL

COMPARISON

[illegible][illegible]

MaxiTPMS ITS600 Display Tablet

Functional Description



The diagram shows a rectangular display tablet with rounded corners. It has a black bezel and a large central screen. The text 'MaxiTPMS' is printed at the top of the bezel, and 'AUTOL' is printed at the bottom. Six numbered callouts point to specific features: 1 points to the top bezel, 2 points to the top-left corner, 3 points to the top-right corner, 4 points to the bottom bezel, 5 points to the bottom-left corner, and 6 points to the bottom-right corner.

Figure 2-1 Display Tablet Front View

- 5.5" LCD Capacitive Touchscreen
- Ambient Light Sensor – detects ambient brightness.
- Power LED – indicates battery level & charging or system status.
- TPMS Service Symbol – indicates the position of the embedded TPMS antenna.
- Lock/Power Button – long press the button to turn on the tablet.

The power LED displays green, yellow or red depending on power level and operating state:

- Green
 - Flashes green when the Display Tablet is charging; lights green when the Display Tablet is fully charged.
- Red
 - Illuminates red when the Display Tablet is powered on and when a

[illegible]