




MODEL 5045 TIRE SPREADER

Repair Parts Information



ITEM NO.	PART NO.	NO. REQ'D	DESCRIPTION	ITEM NO.	PART NO.	NO. REQ'D	DESCRIPTION
1	03-0522	2	Hook	19	055-154	18	Locknut
2	028-046	2	Capscrew	20	268-545	2	Spacer
3	028-338	2	Capscrew	21	636-049	2	Leg
4	06-0110	4	Arm	22	013-092	2	Spreader Guide
5	73-1112	1	Handle	23	028-341	4	Capscrew
6	268-544	3	Spacer	24	103-224	2	Arm
7	52-0053	4	Spacer	25	73-1111	2	Adjustment Block
8	06-0111	2	Arm	26	71-0128	1	Bracket
9	108-141	8	Washer	27	020-024	4	Cap
10	110-083	1	Extension Spring	28	026-628	1	Caution Decal
11	108-015	8	Washer	29	149-316	2	Rod
12	06-0112	2	Arm	30	40-0090	1	LED Lamp
13	50-0167	6	Capscrew	31	20-0013	4	Bushing
14	028-122	6	Capscrew	32	54-0051	2	Quick Release Pin
15	73-0233	2	Bracket	33	01-0198	1	Extension Damper
16	80-0349	1	Model Decal	34	028-022	1	Capscrew
17	028-021	3	Capscrew	35	963-028	2	Roller
18	268-543	6	Spacer		05-0056	1	Storage Cabinet (Optional)

Branick Industries, Inc. • 4245 Main Avenue • P.O. Box 1937 • Fargo, North Dakota 58103

COMMERCIAL WARRANTY

This product is warranted by BRANICK INDUSTRIES, INC. to the original user-owner against defective materials or workmanship for a period of one year from the date of shipment. During the warranty period, at the discretion of Branick management, if the product is found to be defective, it will be repaired or replaced without charge. For service, contact Branick (800-437-4394) to obtain an RMA. Any product shipped to Branick must have an RMA and proof of original shipment date. The repaired or replacement product will be returned with transportation charges prepaid by Branick.

This warranty does not cover defects in the product caused by ordinary wear and tear, abuse, misuse, overloading, accident (including shipping damage), improper maintenance, alteration, or any other cause not the result of defective materials or workmanship.

REPAIR OR REPLACEMENT IS THE EXCLUSIVE REMEDY FOR DEFECTIVE PRODUCT UNDER THIS WARRANTY. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANT ABILITY OR ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OF THIS PRODUCT. BRANICK INDUSTRIES, INC. SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES.

BRANICK INDUSTRIES, INC. reserves the right to make changes in the design or construction of our products without obligation to incorporate such changes in products already sold and without notice.

Service parts and regular repair service are available from authorized distributors of Branick products, or from:

BRANICK INDUSTRIES, INC.
4245 Main Ave.
Fargo, North Dakota 58103
Toll Free: 800-437-4394



www.branick.com